



Autofire LED and button

Button 3

Button 2

Button 1

Start button

Joystick  
bottom view



Jaka  
Arcade  
Controls  
Encoder

Wiring diagram

J-ACE

9.4.2020

<http://kair.us/>